Department of Computer Science Technology

Data Science Technology Program

CET141 - Database Management Systems

Spring 2024 - Sheet #1 Instructors: Dr. Alyaa Hamza

Eng. Hager Sobeah - Eng. Mahmoud ElSahhar - Eng. Mahmoud Heidarl




Topics Covered:

- Setup
 - MySQL Server Installation
 - MySQL Workbench Installation

Installation Steps:


- 1. Download MySQL Installer 8.0.36 through the following link:

 https://dev.mysql.com/get/Downloads/MySQLInstaller/mysql-installer-web-community-8.0.36.0.msi
 - MySQL Community Downloads
 - MySQL Installer






2. After clicking on the .msi file, the following window opens. Make sure to select "Full" to install MySQL Server & MySQL Workbench, then click Next.




3. Review products that will be downloaded then click "Execute".






4. After downloading all products click "Next" and "Execute" the installation.




5. Then click "Next" to start the configuration:






6. In the Server Configuration Type choose "Development Computer" and keep the rest of the fields with their default values.




7. In the Authentication Method keep the default choice to use pass:







8. Then write the password you want to be used for the Root Account.




9. For the Windows Service and Server File Permissions keep the default choices then apply the configuration.














10. After configuring MySQL Server we will start configuring MySQL Router in which we will leave the default values for all fields.









11. Then we will start configuring Samples and Examples:




12. We will need to connect to our Server by entering Username "Root" and the "Root password" we entered in step 8, then click "check", after status change to "Connection Succeeded", click "Next" and Apply the configuration:











13. At this step we completed all the configurations and installed MySQL Server & MySQL Workbench:

